

bronte Linear Drain™ Installation Guide using Full Mortar Bed Adapter Kit

U.S. Patent No. 8,474,068
Patents Pending: Canada &
EP Publication No. 2354339


Discard Linear Drain installation instructions and refer to these instructions for Full Mortar Bed Adapter Kit. Carefully review all installation options and instructions before proceeding.

Full Mortar Bed Adapter Kit Hardware and Materials


 **Bracket Screw**
#8 1/2" Phillips Pan Head
Screws

 **Strainer Height Adjustment Screw**
#10 2-1/2" Phillips Flat
Head Screws. **Note:**
Replaces Strainer Height
Adjustment Screws from
FreeStyle Linear Drain


 **Strainer to Base Screw**
#6 2-1/4" Phillips Pan
Head Screws. **Note:**
Replaces Strainer to Base
Screws from FreeStyle
Linear Drain




Brackets




Foam Block



Mortar Guard




Shower Pan Liner
Square footage amount
ordered separately based on
shower size. Must comply
with state and local codes
Note: Replaces NobleSeal®
Flashing from FreeStyle
Linear Drain



Outside Corner
Select outside corner
material to match Shower
Pan Liner material, PVC or
CPE. Outside Corners
ordered separately.

bronte™ Linear Drain (Ordered Separately) Includes:



Hardware and Materials

 **Pre-Strainer Screw**
#8 1/2" Phillips Pan Head
Screws. 24", 30", 40" Kit
Includes 4. 48", 54", 60"
Kit Includes 2.


 **Clamping Collar
Screw**
#6 5/8" Phillips Flat
Head Screws

 **Strainer to Base Screw**
#6 1" Phillips Pan Head
Screws

 **Strainer Height
Adjustment Screw**
#10 1-1/4" Phillips
Flat Head Screws


 **Base to Sub-Floor Screw**
#8 2-1/2" Phillips Course
Deck Screws

 **Base to Sub-Floor,
Concrete Anchor**
1" Long 1/4" Hole



**Strainer Height
Adjustment Tool**

Tube NobleSealant 150



**NobleSeal®
Flashing**

Note: Shower Pan Liner will be used to waterproof entire shower, this flashing will not be needed.

Pre-Planning

Be certain to gather all required tools and materials required prior to installation.

Sub Floor

Caution: Sub floor must meet local code requirements and Tile Council of North America (TCNA) guidelines.


Clean sub floor to be sure it is smooth and level.

Pre-Sloped and Full Mortar Bed Requirements


Follow manufacturers instructions.

Use products recommended for the type of sloped bed being installed.

bronte Linear Drain assembly is intended to install tight to toe plate and studs within shower prior to installation of mortar bed, backer board, waterproofing and tile.



If bronte Linear Drain assembly is installed inside toe plates within shower, add a properly sloped mortar bed to fill the space between the toe plates and the drain base.




Note: If you are planning to install two drains, side-by-side, refer to Strainer Grate Connector Kit Installation Instructions. The drain bases must be installed 1/4" apart and be "in plane." It may be necessary to use shims, mortar, etc. under the shorter drain to achieve an "in plane" surface alignment with the other drain.

Drain Sizes

Confirm Drain Size, Waste Pipe Type and Waste Pipe Location


Drain hole is off-set to accommodate floor joist location.

Size of shower determines size of drain to be used, which determines location of waste pipe through sub-floor. Match 2" I.D schedule 40 pipe type (PVC or ABS) to drain base type.




Typical Drain Locations


Drain Locations




Back Wall
Flush to back wall
Layout 1




Full Curb
Flush to curb
Layout 2



Partial Curb
Flush to curb
Layout 3



Curb-less
Flush to both side walls
Layout 4




On Centre
Flush to both side walls
Layout 5

1 Wall Preparation

Blocking

Blocking between studs may be needed for Shower Pan Liner attachment prior to drain installation.




2 Sub-Floor Preparation

Caution: Confirm that sub-floor meets all local code requirements and the Tile Council of North America's (TCNA) guidelines.

Check for Level. Clean

Sub-floor must be smooth and level.
Clean sub-floor.




3 Waste Pipe

No Waste Pipe Installed


A Place, Mark and Cut

Place drain base in desired location on sub floor. Mark waste pipe location on sub-floor. Cut opening in sub-floor to access plumbing below.



Install Waste Pipe


Follow local plumbing codes to properly install and secure 2" I.D. waste pipe 3/4" above sub-floor. **Note:** Waste pipe may be installed after fastening drain base if accessible from below.




B Waste Pipe Pre-Installed

Dry fit drain base over location of existing waste pipe. If location does not allow drain base to fit flush against at least 2 shower walls, move location of plumbing to allow for proper installation. May also require moving existing studs and toe plate.

Dry Fit




Alternate Drain Mounting Methods



4 Preparation for Pre-Sloped Bed

Mark Bed Slope

1/4" per foot slope to drain is required.




5 Fasten Drain Base to Sub-Floor

For Concrete Sub-Floor A & B

For Wood Sub-Floor B only

A Mark For Anchors

Dry fit drain base over waste pipe. Mark all holes in outside flange of drain base on concrete floor. Remove drain base. Drill 1/4" holes, 1-1/2" deep where marked. Drive plastic anchors flush in all holes.



5 Continued. Fasten Drain Base to Sub-Floor


B Install Drain Base to Waste Pipe and Sub-Floor

Caution: Confirm proper plastic pipe cement and primer for drain base type (PVC or ABS). Check drain base label to confirm.

Apply appropriate plastic pipe cement and primer to drain and waste pipe following local plumbing codes and manufacturers instructions.

Fit and fully seat drain base onto waste pipe.

Fasten drain base to sub-floor by screwing 2-1/2" deck screws through all holes in outside flange of drain base into plastic anchors or directly into wood sub-floor. **Do not over-tighten.**




6 Pre-Sloped Bed Installation

Protect Drain Base.

Apply tape over entire top surface of drain base.

Install Pre-Sloped Bed


Follow industry standards to complete pre-sloped bed installation. If using mortar, be certain mortar completely fills void below drain base flange. Allow to dry before proceeding.



Making Corners


Tucked Corner (when space is available between studs)

Fold and crease to size. Tuck Shower Pan Liner into space between studs.



Folded Corner

Fold and crease to size. Fold corners behind Shower Pan Liner.




7 Prepare Shower Pan Liner

Drain at Back Wall Layout 1

Shower Pan Liner must turn up the walls a minimum of 3" above finished shower curb and 6" above floor in showers without curbs.

Measure width of shower floor across drain base. Lay Shower Pan Liner flat. Measure and mark Shower Pan Liner.

Fold and crease for upturns and create corners. **Note:** Do not secure Shower Pan Liner at this time.



7 Continued. Prepare Shower Pan Liner

Drain at Full Curb Entry Layout 2

Shower Pan Liner must turn up the walls a minimum of 3" above finished shower curb and 6" above floor in showers without curbs.


Prior to installing Shower Pan Liner, install pre-formed outside corners available separately from Noble Company following manufacturer's instructions. 2 per side.

Measure width of shower floor across drain base. Measure up and over curb. Lay Shower Pan Liner flat. Measure and mark Shower Pan Liner.


Cut, fold and crease to proper size and fit. **Note:** Do not secure Shower Pan Liner at this time.

Note: Noble Curb may also be used. See manufacturer's instructions.

Inside Shower



Outside Shower



7 Continued. Prepare Shower Pan Liner



Drain at Partial Width Curb Layout 3

Shower Pan Liner must turn up the walls a minimum of 3" above finished shower curb and 6" above floor in showers without curbs.


Prior to installing Shower Pan Liner, install pre-formed outside corners available separately from bronte following manufacturer's instructions. 2 per side.

Measure width of shower floor across drain base. Measure up and over curb. Lay Shower Pan Liner flat. Measure and mark Shower Pan Liner.


Cut, fold and crease to proper size and fit. **Note:** Do not secure Shower Pan Liner at this time.

Note: bronte™ Curb may also be used. See manufacturer's instructions.

Inside Shower



Outside Shower



7 Continued. Prepare Shower Pan Liner



Drain at Curb-less Entry Layout 4


Shower Pan Liner must turn up the walls a minimum of 3" above finished shower curb and 6" above floor in showers without curbs.

Prior to installing Shower Pan Liner, install pre-formed outside corners as needed, available separately from bronte following manufacturer's instructions.


Measure width of shower floor across drain base. Lay Shower Pan Liner flat. Measure and mark Shower Pan Liner.

Cut, fold and crease to proper size and fit. **Note:** Do not secure Shower Pan Liner at this time.

Inside Shower



Outside Shower




Drain On Center Layout 5

Shower Pan Liner must turn up the walls a minimum of 3" above finished shower curb and 6" above floor in showers without curbs. Prior to installing Shower Pan Liner, install pre-formed outside corners as needed, available separately from bronte following manufacturer's instructions.

Measure width of shower floor across drain base. Lay Shower Pan Liner flat. Measure and mark Shower Pan Liner.

Fold and crease for upturns. **Note:** Do not secure Shower Pan Liner at this time. Noble Curb may also be used. See manufacturer's instructions.




8 Secure Shower Pan Liner

A Seal Drain Base

Lift out Shower Pan Liner. Remove tape, leaving tape over drain hole only.

Apply a 1/8" continuous bead of NobleSealant 150 around chamfer on base flange and another bead in groove on drain base.




B Pre-Formed Corners

Apply NobleSealant 150 to any pre-formed corners.


C Press Shower Pan Liner into Sealant

Align Shower Pan Liner, fit or re-tuck corners and firmly press Liner into sealant on drain base and any pre-formed corners.



9 Fasten Shower Pan Liner


Nail through top 1" of Shower Pan Liner to studs and/or blocking.



10 Install Clamping Collar


Align collar with drain base under Shower Pan Liner. Press firmly. Starting at one end, insert 5/8" screw through collar, punch through Shower Pan Liner and screw into base. Repeat for all screws.

Do not over-tighten.



11 Cut Out Flashing

With a razor knife, carefully trim out Shower Pan Liner from center of collar. Remove tape from drain hole. **Caution:** Do not puncture Shower Pan Liner outside of collar.



12 Flood Test


Flood test as required by local codes.

13 Drain

Drain and dry after successful flood test.


14 Install Brackets

Align holes in Bracket with second set of holes in from end of drain base. Attach using two 1/2" screws. Repeat for opposite end of drain base. **Do not over-tighten screws.**




15 Install Foam Block

Lay Foam Block in brackets and align ends of foam with inside edge of Clamping Collar.




16 Install Mortar Guard

Install Mortar Guard over Foam Block and Brackets. Center end to end over Clamping Collar. Fully seat Mortar Guard to Clamping Collar on Drain Base.




17 Install Mortar Bed

Follow industry standards to install mortar bed flush to top of Mortar Guard 1-1/4" thick. Pack mortar into top and bottom of T-Channels to lock Mortar Guard in place. Be certain to maintain uniform thickness within entire bed. Allow to dry before proceeding.



18 Remove Foam Block and Brackets

Carefully remove Foam Block. Remove Bracket Screws and Brackets.



19 Install Backer Board and Wall Waterproofing

Note: Plumbing codes and TCNA guidelines state that shower walls must be sealed with a vapor barrier or waterproofing membrane.


Install 1/2" backer board and wall waterproofing according to manufacturer's instructions.

Caution: Do not puncture Liner.

20 Install Pre-Strainers


Place short leg of Pre-Strainer down, facing drain hole. Install 1/2" pan head screw, align strainer grate and tighten screw. Repeat for opposite strainer grate.

Note: On 24" drain, place long leg of Pre-Strainer down, facing drain hole.



21 Install Height Adjustment Screws


Screw in all 2-1/2" flat head height adjustment screws to approximately 1-5/8" above the clamping collar.



22 Temporarily Attach Strainer Grate

Note: Strainer grate attachment holes are not symmetrical. If screws do not align with holes in drain base, turn strainer grate end-to-end.

Place strainer grate over height adjustment screws. Temporarily fasten with three 2-1/4" pan head screws. **Do not over-tighten.**




23 Tile and Grout

Be certain strainer grate is protected with tape.

Allow for 1/16" clearance between strainer grate and tile.

Caution: Do not grout or seal this space.


Tile and grout all surfaces following manufacturer's instructions and TCNA guidelines.



24 Adjust Strainer Grate Height

Remove strainer grate. Remove tape from strainer grate. If factory installed film, start peeling at one end of strainer grate. Peel side to side (saw tooth pattern) to other end of strainer grate. Remove remaining residue by wiping with a soft cloth and WD40™ or Goo Gone™.

Place thin end of height adjustment tool on tile and rest other end on height adjustment screw. Adjust screw for level. Repeat for all height adjustment screws.




25 Re-Install Strainer Grate

Note: Strainer grate attachment holes are not symmetrical. If screws do not align with holes in drain base, turn strainer grate end-to-end.

Place strainer grate over height adjustment screws. Confirm that strainer grate is flush with all tiles. Fasten with three 2-1/4" pan head screws.


Do not over-tighten.



Cleaning Drain

To clean drain, remove 3 screws in top of strainer grate. Clear any hair or other obstructions from drain.

Remove Strainer Grate




Re-Attach Strainer Grate

Note: Strainer grate attachment holes are not symmetrical. If screws do not align with holes in drain base, turn strainer grate end-to-end.

Place strainer grate over height adjustment screws.

Replace all three screws.

Do not over-tighten.



Other shower products available from bronte™.

NobleSeal TS waterproofing membrane

bronte™ CPE outside corners

WallSeal for vertical waterproofing

bronte™ Niches

bronte™ Benches

bronte™ Curbs

U.S. Patent No. 8,474,068

Patents Pending: Canada & EP Publication No. 2354339

© NobleSeal is a registered trademark of Noble Company, Grand Haven, MI.

bronte™ is a trademark of Oakville Stamping & Bending Ltd.



2200 Speers Road
Oakville, ON. L6L 2X8
www.brontecollection.ca