

# bronte Linear Drain™ Tile Top Strainer Grate Full Mortar Bed Adapter Kit



bronte Linear Drain - Full Mortar Bed Adapter Kit  
Instruction Guide: **STEP 14**


*Use these screws to secure the Brackets.*



bronte Linear Drain - Full Mortar Bed Adapter Kit  
Instruction Guide: **STEP 21**

bronte Linear Drain - Tile Top Strainer Grate Instruction  
Guide: **STEP 3.1**

*These are the 10-24 x 2-1/4" Flat Phillips Head Strainer Height  
Adjustment Screws for a Tile Top Strainer Grate when used with  
a Full Mortar Bed Adapter Kit.*



[Actual Size of Screw]



Installation of stand-off pins into end of Linear Drain base.

bronte Linear Drain - Tile Top Strainer Grate  
Instruction Guide: **STEP 3.2**

*Screw these two (2) stand-offs into the drain, one at each  
end of the drain base. The pins on the Tile Top Strainer  
will slip into the holes on the top of these stand-offs.*



Installation of Tile Top Strainer Grate pins into stand-offs.



2200 Speers Road  
Oakville, ON. L6L 2X8  
[www.brontecollection.ca](http://www.brontecollection.ca)

U.S. Patent No. 8,474,068  
Patents Pending: Canada & EP Publication No. 2354339  
bronte™ is a trademark of Oakville Stamping & Bending Ltd.



PMG 1065 File No. 7249